DCS DIGITAL CROSS-POINT SWITCH

QUICK START GUIDE

DCS-72 Video Chassis



STEP 3: Connect an active network cable and local display and KMASS devices to the DCS CPU. Install the DCS's two supplied AC power cords into the two power supplies and plug them into a standard AC source to turn the unit ON.

STEP 5: Connect the display and KMASS devices at the Transmitter. Install the Transmitter's supplied AC power cord and turn the unit ON. Turn the CPU on and verify that all system functions are working properly.



The DCS will be turned ON when either AC power cord is plugged into an AC source.



STEP 1: Connect the video and KMASS devices at the Receiver. Install the receiver's supplied AC power cord and turn the unit ON.

STEP 4: Connect your multi-mode fiber-optic cables between the Transmitter and the DCS IN ports. For KMASS fibers, connect the transmit fiber L1 of the transmitter to an R (receive) connector and the receive fiber L2 to a T (transmit) connector on the KMASS card.

STEP 2: Connect your multi-mode fiber-optic cables between the Receiver and the DCS OUT ports. For KMASS fibers, connect the transmit fiber L2 of the receiver to an R (receive) connector and the receive fiber L1 to a T (transmit) connector on the KMASS card.

The Thinklogical™ Digital Cross-point Switch is an electrical to optical and optical to electrical switch used exclusively with Thinklogical™ KVM extenders. Multimode fiber(s) connect the Input/ Output modules of the DCS to any of the Thinklogical™ KVM extenders.



DCS **KMASS Chassis** INPUT/OUTPUT Cards.

DCS KMASS Chassis



DCS **Video Chassis** INPUT/OUTPUT Cards.

DCS Video Chassis

thinklogical™

PHONE: (800) 291-3211
WEBSITE: www.thinklogical.com
EMAIL: support@thinklogical.com

*Visit us online at **www.thinklogical.com** for more product information, current updates and the complete line of Thinklogical™ products.*