QUICK START GUIDE

Camera Fiber-Link CFL-3000 Hi-Speed Base

Thinklogical's Camera Fiber-Link System® uses a Camera Side Unit and a Frame Grabber Side Unit connected by duplex, multi-mode, fiber-optic cables to allow Camera Link video support up to 500 meters (1640 feet) from the host computer with no loss of signal or resolution and without the use of amplifiers or repeaters of any kind.


With Thinklogical's industrial enhancements, the Camera Fiber-Link System is ideal for any application.

- Supports all Camera-Link base/medium/full configurations with a pixel clock from 20-85MHz.
- Threaded screw-lock in put power connectors
- Compact, light-weight design

STEP 1: Verify the contents.

When you receive your Thinklogical® CFL-3000 Camera Fiber-Link system, you should find the following items:

- Camera Fiber-Link (CFL-3000 Camera Side) Transmitter
- Camera Fiber-Link (CFL-3000 Frame Grabber Side) Receiver
- 5VDC Power Supply Quantity 2
- MDR-26 Cable, 2 Meters (CBL-000007-002MR) Quantity 1
- Camera Fiber-Link Adapter/Cable Kit (KIT-000013-R) Quantity 1



er

1
antity 1
e
ty 2

STEP 6: Connect the 5VDC power supply (PWR-000022-R) to the Frame Grabber Side Unit (Rx) and plug it into a standard AC source.


(CFL-003000-LCRX)

CAMERA FIBER-LINK® Digital Camera Extension System CFL-3000
HI-SPEED BASE FRAME GRABBER SIDE

Powered by MRTS Technology

Powered by MRTS Technology

CAMERA FIBER-LINK® Cable (CBL-000007-002MR), connect the CPU's frame grabber to the Frame Grabber Side Unit (Rx).



STEP 8: Open your frame grabber

application. Verify that all system

features are functioning properly.



STEP 2: Connect multi-mode fiber optic cables between the Frame Grabber side unit and the Camera side unit (up to 500 meters). Be sure not to kink or pinch the cables and keep all bend radii to no less than 3 inches.

Connect:

L1 to L1 and L2 to L2

Multi-Mode Fiber models are available with SC-, ST-, or LC-type fiber connectors.

To complement its line of Camera Fiber-Link extenders, Thinklogical also offers high performance **USB 2.0** and **Firewire 800** Camera Extenders. Please contact a Thinklogical sales representative for details.



STEP 5: If using external sensors, lighting, etc., two CAT5 cables and RJ45 to DB9M and DB9F adapters (KIT-000013-R) are included to connect your serial device(s) through the Camera Side and Frame Grabber Side units.

STEP 4: Using an MDR-26 cable connect the camera to the Camera Side Unit (Tx) and turn the camera ON.





Local Display

Camera Fiber-Link Sample Rate:

- Communications from Camera to Frame Grabber, SerTFG—Differential pair with serial communications to the Frame Grabber, sampled at 97MHz.
- Communications from Frame Grabber to Camera, SerTC—Differential pair with serial communications to the Camera, sampled at 97MHz.
- Camera Control 1 (CC1), Camera Control 2 (CC2), Camera Control 3 (CC3), Camera Control 4 (CC4) are sampled at 97MHz.
- Serial Port Communications are sampled at ~32MHz from Camera to Frame Grabber (RX, DSR, CTS) and at 97MHz from Frame Grabber to Camera (RTS, TX, DTX).



PHONE: WEBSITE: EMAIL:

IE: 1-800-291-3211
SITE: www.thinklogical.com
L: support@thinklogical.com

Copyright © 2012. All rights reserved. Printed in the U.S.A. All trademarks and service marks are the property of their respective owners.

CFL-3000 Quick Start Rev D.